




# FORTIS ELECTRICAL HARNESS

## with hydraulic central and hydraulic distributor

HARNESS N°	5657504	5657506	5657513	5657513	5657514	5657519	5657523	5657523	5657524	5657525	5657533	5657533	5657534	5657534	5657535	5657535	5657537	5657537	5657539	5657540	5657540	5657541
Plug to supply		4	23B	23B	35A		35A	35A	1	1	35A	35A	35A	35A	35A	35A	35B	35B	35A	23B	23B	23B
Fortis 2600 - 3300																						
Fortis 4300																						
Valves compartment																						
Tractor																						
1 Module				5657530			X		X		X		X		X		X				5657530	5657530
Module to spray								X		X		X		X		X						
Module to hydraul.			5657566		5657574					X								X	5657574	X		
Shunt box	X					X			X	X												
VOLUTIS control box																						
AUTONET																						
Solenoid valves to spray							7 SV	7SV			4 SV	4SV										1 SV
Solenoid valves of return							X	X			X	X	X	X	X	X						
Pneumatic solenoid valves AGP													4 SV	4SV	7 SV	7SV						
Flowmeter to spray																						
Flowmeter to filling																						
Filling valve																						
Motor-driven valve																						
Buzzer to boom																	X	X				
Main tank full level buzzer alarm																						
Main tank full level sensor																						
Rinse tank low level sensor																						
Speed pickup																						
Hydrauma 4 + hydraulic central			X	X													9SV	9SV		6SV	6SV	6SV
Hydraulic control selector																	2 SV	2SV				
Latch boom (hydraul.)																				2 SV	2 SV	2 SV
Latch boom (contact.)																	X	X				
3/4 folding boom																				2 SV	2 SV	2 SV
GV boom			2 SV	2 SV													2 SV	2SV		2 SV	2 SV	2 SV
U/F arm of boom (hydraul.)																	2 SV	2SV				
U/F arm of boom (contact.)																						
U/F boom fore-arm																	2 SV	2SV				
Up/down boom lift																	1 SV	1SV				
Tilt correction of boom (hydraul.)																	2 SV	2SV				
Tilt correction of boom (contact.)																						
Tracking axle tree		X																	8 SV			
Corrector axle tree or draw-bar with reset					8 SV																	
Air bag suspension Axair																						
Air compressor	X					AGP																
Plug 1																						
Plug 2							X	X			X	X	X	X	X	X						
Plug 3																						
Plug 4																			X			



 MODULE to SPRAY  
 MODULE to HYDRAUL  
 ONE MODULE only

# FORTIS ELECTRICAL HARNESS

## with hydraulic central and hydraulic distributor

5657543	5657544	5657545	5657546	5657551	5657555	5657560	5657561	5657562	5657562	5657563	5657563	5657564	5657565	5657572	5657573	5657576	5657577	HARNESS N°
2	2	2	2	23B	1	23B		35B	35B	35B	35B	3	1	23 B	23B	23 B	3	Plug to supply
X	X											X						Fortis 2600 - 3300
		X	X														X	Fortis 4300
							X											Valves compartment
							X											Tractor
					X				X		X							1 Module
				5657528		5657528							X	5657528	5657528	5657528		Before module to spray
								X		X			X					Behind module to hydraul.
							X											Shunt box
																		VOLUTIS control box
																		AUTONET
				4 SV		2 SV									2 SV	4 SV		Solenoid valves to spray
																		Solenoid valves of return
																		Pneumatic solenoid valves AGP
X	X	X	X															Flowmeter to spray
												X					X	Flowmeter to filling
												X					X	Filling valve
X	X	X	X															Motor-driven valve
								X	X	X	X							Buzzer to boom
X	X	X	X															Main tank full level buzzer alarm
X	X	X	X															Main tank full level sensor
																		Rinse tank low level sensor
X		X																Speed pickup
								9 SV	9SV	9 SV	9SV							Hydrauma 4 + hydraulic central
								2 SV	2SV	2 SV	2SV							Hydraulic control selector
																		Latch boom (hydraul.)
								X	X	X	X							Latch boom (contact.)
																		3/4 folding boom
																		GV boom
								2 SV	2SV	2 SV	2SV							U/F arm of boom (hydraul.)
								X	X	X	X							U/F arm of boom (contact.)
								2 SV	2SV	2 SV	2SV							U/F boom fore-arm
								1 SV	1SV	1 SV	1SV							Up/down boom lift
								2 SV	2SV	2 SV	2SV							Tilt correction of boom (hydraul.)
										X	X							Tilt correction of boom (contact.)
																		Tracking axle tree
																		Corrector axle tree or draw-bar with r
																		Air bag suspension Axair
																		Air compressor
																		Plug 1
																		Plug 2
														X	X	X		Plug 3
																		Plug 4



	MODULE to SPRAY
	MODULE to HYDRAUL
	ONE MODULE only

# FORTIS ELECTRICAL HARNESS

## with hydraulic central and hydraulic distributor

[illegible]

# FORTIS ELECTRICAL HARNESS

## with hydraulic central and hydraulic distributor

HARNESS N°	
Plug to supply	
Fortis 2600 - 3300	
Fortis 4300	
Valves compartment	
Tractor	
1 Module	
Before module to spray	
Behind module to hydraul.	
Shunt box	
VOLUTIS control box	
AUTONET	
Solenoid valves to spray	
Solenoid valves of return	
Pneumatic solenoid valves AGP	
Flowmeter to spray	
Flowmeter to filling	
Filling valve	
Motor-driven valve	
Buzzer to boom	
Main tank full level buzzer alarm	
Main tank full level sensor	
Rinse tank low level sensor	
Speed pickup	
Hydrauma 4 + hydraulic central	
Hydraulic control selector	
Latch boom (hydraul.)	
Latch boom (contact.)	
3/4 folding boom	
GV boom	
U/F arm of boom (hydraul.)	
U/F arm of boom (contact.)	
U/F boom fore-arm	
Up/down boom lift	
Tilt correction of boom (hydraul.)	
Tilt correction of boom (contact.)	
Tracking axle tree	
Corrector axle tree or draw-bar with reset	
Air bag suspension Axair	
Air compressor	
Plug 1	
Plug 2	
Plug 3	
Plug 4	