

HARNESS N°	6E+06	5657504	5657506	5657513	5657513	5657514	5657519	5657523	5657523	5657524	5657525	5657533	5657533	5657534	5657534	5657535	5657535	5357536	5657537	5657537
Plug to supply			4	23B	23B	35A		35A	35A	1	1	35A	35A	35A	35A	35A	35A		35B	35B
Battery	6²																			
Lighting lateral chest																				
Plug tractor																				
Fortis 2600 - 3300																				
Fortis 4300																				
Valves compartment																				
Tractor																				
1 Module					5657530			X		X		X		X		X			X	
Module to spray									X		X		X		X		X			
Module to hydraul.				5657566		5657574					X									X
Ergo handle																		X		
AVENTA Box control	X																	X		
Shunt box		X					X			X	X									
VOLUTIS control box																				
AUTONET																				
Solenoid valves to spray								7 SV	7SV			4 SV	4SV							
Solenoid valves of return								X	X			X	X	X	X	X	X			
Pneumatic solenoid valves AGP														4 SV	4SV	7 SV	7SV			
Flowmeter to spray																				
Flowmeter to filling																				
Filling valve																				
Motor-driven valve																				
Buzzer to boom																			X	X
Main tank full level buzzer alarm																				
Main tank full level sensor																				
Rinse tank low level sensor																				
Speed pickup																				
Hydrauma 4 + hydraulic central				X	X														9SV	9SV
Hydraulic control selector																			2 SV	2SV
Latch boom (hydraul.)																				
Latch boom (contact.)																			X	X
3/4 folding boom																				
GV boom				2 SV	2 SV														2 SV	2SV
U/F arm of boom (hydraul.)																			2 SV	2SV
U/F arm of boom (contact.)																				
U/F boom fore-arm																			2 SV	2SV
Up/down boom lift																			1 SV	1SV
Tilt correction of boom (hydraul.)																			2 SV	2SV
Tilt correction of boom (contact.)																				
Tracking axle tree			X																	
Corrector axle tree or draw-bar with reset						8 SV														
Air bag suspension Axair	X	X					X													
Air compressor		X					AGP													
Plug 1	X												X	X	X	X	X			
Plug 2								X	X											
Plug 3																				
Plug 4																				
<div><div></div><div>5657536 Bundle + Handful</div></div> <div><div>AUTONET</div><div>AUTONET</div><div>AUTONET</div><div>AUTONET</div><div>AUTONET</div><div>AUTONET</div><div>AUTONET</div><div></div></div>																				

5657539	5657540	5657540	5657541	5657543	5657544	5657545	5657546	5657551	5657555	5657560	5657561	5657562	5657562	5657563	5657563	5657564	5657565	5657572	5657573	5657576	5657577	HARNESS N°
35A	23B	23B	23B	2	2	2	2	23B	1	23B		35B	35B	35B	35B	3	1	23 B	23B	23 B	3	Plug to supply
																						Battery
																						Lighting lateral chest
																						Plug tractor
				X	X											X						Fortis 2600 - 3300
						X	X														X	Fortis 4300
											X											Valves compartment
											X											Tractor
		5657530	5657530						X				X		X							1 Module
								5657528		5657528							X	5657528	5657528	5657528		Before module to spray
5657574	X											X		X			X					Behind module to hydraul.
																						Ergo handle
											X											AVENTA Box control
																						Shunt box
																						VOLUTIS control box
																						AUTONET
			1 SV					4 SV		2 SV									2 SV	4 SV		Solenoid valves to spray
																						Solenoid valves of return
																						Pneumatic solenoid valves AGP
				X	X	X	X															Flowmeter to spray
																						Flowmeter to filling
																X					X	Filling valve
				X	X	X	X															Motor-driven valve
												X	X	X	X							Buzzer to boom
				X	X	X	X															Main tank full level buzzer alarm
				X	X	X	X															Main tank full level sensor
																						Rinse tank low level sensor
				X		X																Speed pickup
	6SV	6SV	6SV									9 SV	9SV	9 SV	9SV							Hydrauma 4 + hydraulic central
												2 SV	2SV	2 SV	2SV							Hydraulic control selector
	2 SV	2 SV	2 SV																			Latch boom (hydraul.)
												X	X	X	X							Latch boom (contact.)
	2 SV	2 SV	2 SV																			3/4 folding boom
	2 SV	2 SV	2 SV																			GV boom
												2 SV	2SV	2 SV	2SV							U/F arm of boom (hydraul.)
												X	X	X	X							U/F arm of boom (contact.)
												2 SV	2SV	2 SV	2SV							U/F boom fore-arm
												1 SV	1SV	1 SV	1SV							Up/down boom lift
												2 SV	2SV	2 SV	2SV							Tilt correction of boom (hydraul.)
														X	X							Tilt correction of boom (contact.)
8 SV																						Tracking axle tree
																						Corrector axle tree or draw-bar with reset
																						Air bag suspension Axair
																						Air compressor
																						Plug 1
																						Plug 2
																		X	X	X		Plug 3
X																						Plug 4



MODULE to SPRAY
MODULE to HYDRAUL
ONE MODULE only

57790	5779001	5779002	5779003	5779004	5779004	5779005	5779005	5779006	5779007	5779008	5779009	5779010	5779011	5779012	5779013	5779014	5779015	5779016	HARNESS N°
2	2	2	2	23B	23B	23B	23B	23B	1	1	1	1	2	2	2	2	2	4x6²	Plug to supply
																			Battery
																			Lighting lateral chest
X	X														X	X			Plug tractor
		X	X											X			X		Fortis 2600 - 3300
																			Fortis 4300
																			Valves compartment
																			Tractor
				5657530		5657530		5657530	X		X								1 Module
					X		5657566			X		X							Before module to spray
																			Behind module to hydraul.
																			Ergo handle
																		X	AVENTA Box control
									X	X									Shunt box
									X	X	X	X							VOLUTIS control box
				1SV	1SV	1SV	1SV	1SV											AUTONET
																			Solenoid valves to spray
															X	X	X		Solenoid valves of return
X	X	X	X										X						Pneumatic solenoid valves AGP
													X						Flowmeter to spray
														X	X	X	X		Flowmeter to filling
X	X	X	X																Filling valve
																			Motor-driven valve
													X						Buzzer to boom
X	X	X	X										X						Main tank full level buzzer alarm
X	X	X	X											X	X	X	X		Main tank full level sensor
X	X	X	X													X	X		Rinse tank low level sensor
X		X																	Speed pickup
				6SV	6SV	2SV	2SV	6SV											Hydrauma 4 + hydraulic central
																			Hydraulic control selector
				2SV	2SV			2SV											Latch boom (hydraul.)
																			Latch boom (contact.)
				2SV	2SV			2SV											3/4 folding boom
				2SV	2SV	2SV	2SV	2SV											GV boom
																			U/F arm of boom (hydraul.)
																			U/F arm of boom (contact.)
																			U/F boom fore-arm
																			Up/down boom lift
																			Tilt correction of boom (hydraul.)
																			Tilt correction of boom (contact.)
																			Tracking axle tree
																			Corrector axle tree or draw-bar with reset
																			Air bag suspension Axair
																			Air compressor
																		X	Plug 1
																			Plug 2
																X	X		Plug 3
																			Plug 4
AUTONET		AUTONET		AUTONET	AUTONET	AUTONET	AUTONET	AUTONET	VOLUTIS	VOLUTIS	VOLUTIS	VOLUTIS							VOLUTIS



MODULE to SPRAY
MODULE to HYDRAUL
ONE MODULE only