


FORTIS ELECTRICAL HARNESS
with hydraulic central and hydraulic distributor

After 2005

HARNESS N°	5779032	5779029	5657506	5657513	5657513	5657514	5779030	5657523	5657523	5779031	5657533	5657533	5657534	5657534	5657535	5657535	5357536	5657537	5657537
Plug to supply			4	23B	23B	35A		35A	35A	1	35A	35A	35A	35A	35A	35A		35B	35B
Battery	10²																		
Lighting lateral chest																			
Plug tractor																			
Fortis 2600 - 3300																			
Fortis 4300																			
1 Module					5657530			X			X		X		X			X	
Module to spray									X			X		X		X			
Module to hydraul.				5657566		5657574													X
Ergo handle																	X		
AVENTA Box control	X																X		
Shunt box		X					X			X									
VOLUTIS control box																			
AUTONET																			
Solenoid valves to spray								7 SV	7SV		4 SV	4SV							
Solenoid valves of return								X	X		X	X	X	X	X	X			
Pneumatic solenoid valves AGP													4 SV	4SV	7 SV	7SV			
Flowmeter to spray																			
Flowmeter to filling																			
Filling valve																			
Motor-driven valve																			
Buzzer to boom																		X	X
Main tank full level buzzer alarm																			
Main tank full level sensor																			
Rinse tank low level sensor																			
Speed pickup																			
Hydrauma + hydraulic central				2SV	2SV													9SV	9SV
Hydraulic control selector																		2 SV	2SV
Latch boom (hydraul.)																			
Latch boom (contact.)																		X	X
Latch between inner and outer arm																			
3/4 folding boom																			
GV boom				2 SV	2 SV													2 SV	2SV
U/F arm of boom (hydraul.)																		2 SV	2SV
U/F arm of boom (contact.)																			
U/F boom fore-arm																		2 SV	2SV
Up/down boom lift																		1 SV	1SV
Tilt correction of boom (hydraul.)																		2 SV	2SV
Tilt correction of boom (contact.)																			
Tracking axle tree			X																
Corrector axle tree or draw-bar with reset						8 SV													
Air bag suspension Axair	X						X			X									
Air compressor		X					AGP			AGP			AGP	AGP	AGP	AGP			
Plug 1	X																		
Plug 2								X	X		X	X	X	X	X	X			
Plug 3																			
Plug 4																			



AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET

5657536 Bundle + Handful

FORTIS ELECTRICAL HARNESS
with hydraulic central and hydraulic distributor

After 2005

5657539	5657540	5657540	5657541	5657543	5657544	5657545	5657546	5657551	5779034	5657560	5657561	5779079	5779079	5657563	5657563	5657564	5657572	5657573	5657576	5657577	HARNESS N°
35A	23B	23B	23B	2	2	2	2	23B	1	23B		35B	35B	35B	35B	3	23 B	23B	23 B	3	Plug to supply
											X										Battery
											X										Lighting lateral chest
																					Plug tractor
				X	X											X					Fortis 2600 - 3300
							X	X												X	Fortis 4300
		5657530	5657530						X				X		X						1 Module
								5657528		5657528							5657528	5657528	5657528		Before module to spray
5657574	X											X		X							Behind module to hydraul.
																					Ergo handle
											X										AVENTA Box control
																					Shunt box
																					VOLUTIS control box
																					AUTONET
			1 SV					4 SV		2 SV								2 SV	4 SV		Solenoid valves to spray
																					Solenoid valves of return
				X	X	X	X														Pneumatic solenoid valves AGP
																					Flowmeter to spray
																X				X	Flowmeter to filling
																X				X	Filling valve
				X	X	X	X														Motor-driven valve
												X	X	X	X						Buzzer to boom
				X	X	X	X														Main tank full level buzzer alarm
				X	X	X	X														Main tank full level sensor
																					Rinse tank low level sensor
				X		X															Speed pickup
	6SV	6SV	6SV									9 SV	9SV	9 SV	9SV						Hydrauma + hydraulic central
												2 SV	2SV	2 SV	2SV						Hydraulic control selector
	2 SV	2 SV	2 SV																		Latch boom (hydraul.)
												X	X	X	X						Latch boom (contact.)
																					Latch between inner and outer arm
	2 SV	2 SV	2 SV																		3/4 folding boom
	2 SV	2 SV	2 SV																		GV boom
												2 SV	2SV	2 SV	2SV						U/F arm of boom (hydraul.)
												X	X	X	X						U/F arm of boom (contact.)
												2 SV	2SV	2 SV	2SV						U/F boom fore-arm
												1 SV	1SV	1 SV	1SV						Up/down boom lift
												2 SV	2SV	2 SV	2SV						Tilt correction of boom (hydraul.)
														X	X						Tilt correction of boom (contact.)
8 SV																					Tracking axle tree
																					Corrector axle tree or draw-bar with reset
																					Air bag suspension Axair
																		AGP	AGP		Air compressor
																					Plug 1
																					Plug 2
																	X	X	X		Plug 3
X																					Plug 4



MODULE to SPRAY
 MODULE to HYDRAUL
 ONE MODULE only

After 2005

Tecnoma 
technologies