



HARNESS N°	5779032	5779029	5657506	5657513	5657513	5657514	5779030	5657523	5657523	5779031	5657533	5657533	5657534	5657534	5657535	5657535	5357536	5657537	5657537
Plug to supply			4	23B	23B	35A		35A	35A	1	35A	35A	35A	35A	35A	35A		35B	35B
Battery	10²																		
Lighting lateral chest																			
Plug tractor																			
Fortis 2600 - 3300																			
Fortis 4300																			
1 Module					5657530			X			X		X		X			X	
Module to spray									X			X		X		X			
Module to hydraul.				5657566		5657574													X
Ergo handle																	X		
AVENTA Box control	X																X		
Shunt box		X					X			X									
VOLUTIS control box																			
AUTONET																			
Solenoid valves to spray								7 SV	7SV		4 SV	4SV							
Solenoid valves of return								X	X		X	X	X	X	X	X			
Pneumatic solenoid valves AGP													4 SV	4SV	7 SV	7SV			
Flowmeter to spray																			
Flowmeter to filling																			
Filling valve																			
Motor-driven valve																			
Buzzer to boom																		X	X
Main tank full level buzzer alarm																			
Main tank full level sensor																			
Rinse tank low level sensor																			
Speed pickup																			
Hydrauma + hydraulic central				X	X													9SV	9SV
Hydraulic control selector																		2 SV	2SV
Latch boom (hydraul.)																			
Latch boom (contact.)																		X	X
3/4 folding boom																			
GV boom				2 SV	2 SV													2 SV	2SV
U/F arm of boom (hydraul.)																		2 SV	2SV
U/F arm of boom (contact.)																			
U/F boom fore-arm																		2 SV	2SV
Up/down boom lift																		1 SV	1SV
Tilt correction of boom (hydraul.)																		2 SV	2SV
Tilt correction of boom (contact.)																			
Tracking axle tree			X																
Corrector axle tree or draw-bar with reset						8 SV													
Air bag suspension Axair	X	X					X			X									
Air compressor		X					AGP			AGP									
Plug 1	X																		
Plug 2								X	X		X	X	X	X	X	X			
Plug 3																			
Plug 4																			



AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET
AUTONET

FORTIS ELECTRICAL HARNESS
with hydraulic central and hydraulic distributor

Between 09/2004 and 12/2004

5657539	5657540	5657540	5657541	5657543	5657544	5657545	5657546	5657551	5779034	5657560	5657561	5657562	5657562	5657563	5657563	5657564	5657572	5657573	5657576	5657577	HARNESS N°
35A	23B	23B	23B	2	2	2	2	23B	1	23B		35B	35B	35B	35B	3	23 B	23B	23 B	3	Plug to supply
											X										Battery
											X										Lighting lateral chest
																					Plug tractor
				X	X											X					Fortis 2600 - 3300
						X	X													X	Fortis 4300
		5657530	5657530						X				X		X						1 Module
5657574	X							5657528		5657528		X		X			5657528	5657528	5657528		Before module to spray
																					Behind module to hydraul.
																					Ergo handle
											X										AVENTA Box control
																					Shunt box
																					VOLUTIS control box
			1 SV					4 SV		2 SV								2 SV	4 SV		AUTONET
																					Solenoid valves to spray
																					Solenoid valves of return
																					Pneumatic solenoid valves AGP
				X	X	X	X														Flowmeter to spray
																X				X	Flowmeter to filling
																X				X	Filling valve
				X	X	X	X														Motor-driven valve
				X	X	X	X					X	X	X	X						Buzzer to boom
				X	X	X	X														Main tank full level buzzer alarm
																					Main tank full level sensor
																					Rinse tank low level sensor
				X		X															Speed pickup
	6SV	6SV	6SV									9 SV	9SV	9 SV	9SV						Hydrauma + hydraulic central
												2 SV	2SV	2 SV	2SV						Hydraulic control selector
	2 SV	2 SV	2 SV																		Latch boom (hydraul.)
												X	X	X	X						Latch boom (contact.)
	2 SV	2 SV	2 SV																		3/4 folding boom
	2 SV	2 SV	2 SV																		GV boom
												2 SV	2SV	2 SV	2SV						U/F arm of boom (hydraul.)
												X	X	X	X						U/F arm of boom (contact.)
												2 SV	2SV	2 SV	2SV						U/F boom fore-arm
												1 SV	1SV	1 SV	1SV						Up/down boom lift
												2 SV	2SV	2 SV	2SV						Tilt correction of boom (hydraul.)
														X	X						Tilt correction of boom (contact.)
8 SV																					Tracking axle tree
																					Corrector axle tree or draw-bar with reset
																		AGP	AGP		Air bag suspension Axair
																					Air compressor
																					Plug 1
																					Plug 2
																	X	X	X		Plug 3
X																					Plug 4



MODULE to SPRAY
 MODULE to HYDRAUL
 ONE MODULE only

Between 09/2004 and 12/2004

Tecnoma 
technologies