



HARNESS N°	5657513	5657582	5657523	5657533	5657534	5657535	5657536	5357537	5657540	5657541	5657581	5657553	5657551	5657554	5657560	5657579	5657565	5657569	5657572
Plug to supply	23B	23B	35A	35A	35A	35A		35B	23B	23B	23B		23B	2	23B	35B	35B		23 B
electrical connection												6²						6²	
Module to spray.			X	X	X	X		X	X			X	5657528		5657528			X	5657528
Module to hydraulic	X							X	X							X	X	X	
Ergo handle							X												
AVENTA control box							X					X						X	
VOLUTIS control box																			
AUTONET																			
Solenoid valves to spray			7SV	4SV						1SV	1SV		4SV		2SV				
Solenoid valves of return			X	X	X	X													
Pneumatic valves of return					4SV	7SV													
Flowmeter to spray														X					
Flowmeter to filling																			
Filling valve																			
Motor-driven valve														X					
Buzzer to boom								X								X	X		
Main tank full level buzzer alarm																			
Main tank full level sensor																			
Rinse tank low level sensor																			
Speed pickup														X					
Extension cable speed pickup LASER 1800																			
Hydrauma + hydraulic central	2SV	6SV						9SV	6SV	6SV						9SV	9SV		
Hydraulic control selector				MODULE to SPRAY				2SV								2SV	2SV		
Latch boom (hydraulic)		2SV		MODULE to HYDRAULIC					2SV	2SV									
Latch boom (contact.)		X						X								X			
3/4 folding boom		2SV							2SV	2SV									
GV bomm	2SV	2SV							2SV	2SV									
U/F arm of boom (hydraul.)								2SV								2SV	2SV		
U/F arm of boom(contact.)																X	X		
U/F boom fore-arm								2SV								2SV	2SV		
Up/down boom lift								1SV								1SV	1SV		
Tilt correction of boom (hydraul.)								2SV								2SV	2SV		
Tilt correction of boom (contact.)																	X		
Right latch											X								
Left latch																X			
Plug 2			X	X	X	X											X		
Plug 3																			X



FOOT-NOTE: To check the marking of the electrical harness on the apparatus



5657573	5657576	5657578	5779017	5779018	5779019	5779020	5779021	5779022	5779023	5779024	HARNESS N°
23B	23 B	3		6²	6²	3	23B	23B	2	23B	Plug to supply
											electrical connection
5657528	5657528				X						Module to spray.
				X	X						Module to hydraulic
											Ergo handle
				X	X						AVENTA control box
				X	X			X			VOLUTIS control box
							1SV	1SV		1SV	AUTONET
2SV	4SV						1SV				Solenoid valves to spray
											Solenoid valves of return
											Pneumatic valves of return
									X		Flowmeter to spray
		X				X					Flowmeter to filling
		X				X					Filling valve
									X		Motor-driven valve
											Buzzer to boom
											Main tank full level buzzer alarm
											Main tank full level sensor
									X		Rinse tank low level sensor
									X		Speed pickup
			X								Extension cable speed pickup LASER 1800
							6SV	6SV			Hydrauma + hydraulic central
											Hydraulic control selector
							2SV	2SV			Latch boom (hydraulic)
											Latch boom (contact.)
							2SV	2SV			3/4 folding boom
							2SV	2SV		2SV	GV bomm
											U/F arm of boom (hydraul.)
											U/F arm of boom(contact.)
											U/F boom fore-arm
											Up/down boom lift
											Tilt correction of boom (hydraul.)
											Tilt correction of boom (contact.)
						X		X			Right latch
											Left latch
											Plug 2
X	X										Plug 3



V
O
L
U
T
I
S

V
O
L
U
T
I
S

A
U
T
O
N
E
T

A
U
T
O
N
E
T

A
U
T
O
N
E
T

FOOT-NOTE: To check the marking of the electrical harness on the apparatus